



ESPUMO

Installation

Skirting boards glued to a flat wall surface supported by the floor in a horizontal orientation indoors. The ends of the skirting board should be connected to an electrical box, socket or wall, in other cases use a plug. Do not leave unprotected ends of the strip. Make corners by cutting the skirting board at an angle of 90° (when using finishes) or at an angle of 45° (without accessories).

